



| PTO SWITCH | |
|------------|-------|
| OFF | D+C |
| ON | B+A |
| START | B+A+E |

| KEY SWITCH | |
|--------------|-------|
| OFF | M+G |
| RUN w/LIGHTS | B+A+L |
| RUN | B+A |
| START | B+S |

| DASH LIGHTS | |
|-----------------------|---------------------------|
| 1: P.T.O. ON | 4: DO NOT ENGAGE P.T.O. |
| 2: DEPRESS LEFT PEDAL | 5: FULL THROTTLE REQUIRED |
| 3: IN REVERSE GEAR | 6: FULL THROTTLE REQUIRED |

MODEL 1415
SERIAL NUMBER (126,001 - 147,087)